

# Start saving today!

Save energy and money in just a few steps.

---

Congratulations on completing the WarmWise Online Energy Audit & Kit Program. After completing the evaluation you should have reviewed your personalized recommendations explaining steps you can take to save more on your natural gas bills. Also, for completing the evaluation you are receiving this free energy efficiency kit to help get the savings started.

## Install items in your water saving energy efficiency kit

Please see the reverse side for installation instructions. We have thoughtfully selected items that work to save energy without sacrificing your comfort.

## You could save even more...

This is just the first step in saving on your natural gas bills with with Columbia's WarmWise Programs. You can also check out our residential furnace, boiler, combi boiler, tankless water heater and smart thermostat rebates.

Visit [ColumbiaGasPA.com/WarmWise](http://ColumbiaGasPA.com/WarmWise) for more information. Some of these energy saving measures may even qualify for additional tax credits. Consult your tax advisor for details.

---

### Christine Rausch

Columbia Gas of Pennsylvania  
WarmWisePA@NiSource.com

Visit [ColumbiaGasPA.com/WarmWise](http://ColumbiaGasPA.com/WarmWise) to see if you may qualify for our income eligible programs.

 **Columbia Gas**<sup>®</sup>  
A NiSource Company



**Bathroom Aerator**



**Kitchen Aerator**



**Shower Head**

## High-Efficiency Faucet Aerators

### How to Install:\*

Carefully remove any existing aerator by twisting the cap to the left. If the cap is too tight, use pliers or a small pipe wrench to remove by hand.

Place the rubber washer inside the end of the new aerator and hand tighten the aerator onto the faucet.

Check the faucet by turning on the cold water. If you detect a leak, tighten the aerator either by hand or gently using pliers. Do not over tighten, and be careful not to scratch if using pliers.

## High-Efficiency Shower Head

### How to Install:\*

Carefully remove the existing shower head by twisting it to the left, using a wrench or pliers if needed. With the old head removed, clean the threads of the exposed pipe.

Use the enclosed Teflon tape to wrap around the cleaned threads four times. Hand tighten the new shower head to the pipe. Using the wrench or pliers, grip the base of the shower head and carefully tighten it enough so that the water does not leak.

Instructions courtesy of ehow.com.

\* Based on information provided by the manufacturer.

Visit [ColumbiaGasPA.com/WarmWise](http://ColumbiaGasPA.com/WarmWise) to see if you may qualify for our income eligible programs.